



www.LGUSA.com

UX565

QUICK START GUIDE



Transferring
Music



Playing
Music



Transmitting
Music to FM Radio



Bluetooth®
Pairing



Taking a Picture/
Recording a Video



Getting to Know Your Phone




Transferring Music

Carry your music library with you. With the ability to store up to approximately 960 songs on your UX565 – with an optional 4GB microSD card – you'll be rockin' out in no time!*

1. Insert your microSD card into the memory port with the gold contacts facing up.
2. The first time you transfer music, you must format the card. Press the **Left Soft Key** for **Menu**, then select **Settings (9) > Memory (7) > Card Memory (3)**.
3. Press the **Right Soft Key** for **Format**, then select **Yes (1)**.
4. Press **OK**, then **BACK**.
5. Select **USB Setting (5)**, then **USB Mass Storage (2)**.
6. Connect a USB cable* from the phone to your PC.
7. The PC will recognize the phone as a **Removable Disk** and a screen will appear. Drag and drop music files on your PC into the **My_Music** folder.
8. When done, disconnect the phone.

*microSD card and USB cable required. Sold separately.





Playing Music

It couldn't be easier to start listening to your favorite tunes. With the external Music Touch Keys, music is at your fingertips!*

1. Insert a microSD card containing music.
2. With the flip closed, press and *hold* the side **Music Key** to activate the music player.
3. Tap ► to begin playing the highlighted song.
4. Tap ►► or ◀◀ to go to the next/previous song. Tap ▲ or ▼ to view the song list.
5. Tap ► to pause/play the music. To exit the music player, open the flip and press **END** twice.

*microSD card required. Sold separately.



Note: You can play music in the background while doing other tasks. Once you have exited the music player with background music enabled, press the side **Music Key** from the idle screen to return to the player.



Transmitting Music to FM Radio

Be your own DJ! The UX565's built-in FM transmitter lets you easily broadcast music to your car radio or home stereo system.

1. With a microSD card containing music inserted in your phone, press the side **Music Key**.
2. Press **OK** to begin playing a highlighted song.
3. Once the song begins, press the **Right Soft Key** for **Options**.
4. Select **Music Transmitter (4)**, then **On (1)**.
5. Set your radio to 88.1 FM (the phone's default setting) to listen.
6. To change the transmit frequency, press the **Right Soft Key** for **Options** > **Music Transmitter (4)** > **Change Channel (3)**. Then use the Navigation Key to select a new channel and press **OK**.




Bluetooth Pairing

Wireless communication goes to a new level with Bluetooth technology. Connect your UX565 to headsets, speakers, and more.





1. Set your Bluetooth accessory into pairing mode.*
2. Press the **Left Soft Key** for **Menu**, then select **Bluetooth (7) > Paired Devices (1)**.
3. Press the **Left Soft Key** for **Search**. When prompted to turn on Bluetooth, press **OK**.
4. Press **OK** to begin a new search.
5. Once the Bluetooth device has been found, highlight it and press **OK**.
6. Enter the passcode* (typically "0000" – 4 zeroes) and press **OK**.
7. Press **OK** to connect with the device.

**Refer to your Bluetooth accessory's user manual for information about initiating pairing mode and the passcode.*




Taking a Picture/Recording a Video

Stay on top of the action with your UX565. Its 1.3 megapixel camera and camcorder let you capture moments right as they happen!

1. To take a picture, press and *hold* the side  **Key**.
To record a video, quickly press  and select **Record Video (2)**.
2. Press **left** or **right** on the Navigation Key to adjust the brightness and **up** or **down** for zoom.* Press the **Right Soft Key** to adjust other camera/video options.
3. Press  to take the picture or start/stop recording.
4. To send your picture/video, press .

**Camera setting of 1280x960 pixels does not support zoom function.*

Note: To take self-portraits with the flip closed, press and *hold*  and use the external **Touch Keys** to take a photo or record a video.



Optional Accessories

Maximize your phone with these cutting-edge accessories at www.LGUSA.com.



Bluetooth Stereo Speakers



Bluetooth Headset (HBM-755)



Bluetooth Headset (HBM-750)



Portable Stereo Speakers



Stereo Headset



Vehicle Power Charger

©2008 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.