

**Getting Started Guide** 

MOTO **Q** 9h global



## **Table of Contents**

Welcome to AT&T			
What's in the Box?	4		
Insert the SIM Card & Battery	5		
Charge the Battery	5		
Insert a Memory Card	6		
Turn On Your MOTO Q™ 9h global	7		
Set Up Your MOTO Q™ 9h global	8		
Connect to AT&T	8		
Learn to Navigate & Type	8		
Make Calls	10		
Set Up Voicemail	10		
Check Voicemail	10		
Text & MMS Messages			
Instant Messaging			
Go to Web Pages			
Shop for Tones, Games, Graphics, & More	15		
Access Your Email	16		
Choose the Best Email Option for You	16		
Set Up Personal Email with Xpress Mail™			
Set Up Self-Service Corporate Email with Xpress Mail™	19		
Set Up IT-Managed Corporate Email	20		
Send & Receive Fmail	21		



## **Table of Contents**

Sync Your Smartphone with Your Computer	22
Sync Contacts, Calendar, Email, Music, & More	22
Use Your MOTO Q <sup>™</sup> 9h global for More than Basics	24
Find Your Way With AT&T Navigator	24
AT&T Music™	26
Record a Video Clip	27
Play a Video Clip	28
Watch CV	29
Watch Live Video with MobiTV	29
Connect a Bluetooth® Wireless Headset	30
Store & Call Contacts	31
Add & View Calendar Events	32
Manage Finances With Mobile Banking from AT&T	33
Troubleshooting & FAQs	34
Tips 9 Tricks	26

The back cover has a fold-out panel with a control diagram of your smartphone. You can leave the fold-out open to reference it as you look through this guide.





### Welcome to AT&T

#### What's in the Box?

Thank you for purchasing the MOTO Q<sup>™</sup> 9h global. Take note of the components in the box, pictured on the right.

To get started, we recommend the following:

- Carefully follow the step-by-step instructions in this quide to set up your MOTO Q<sup>™</sup> 9h global.
- To learn more or if you need help with your MOTO Q<sup>™</sup> 9h qlobal, review the user's quide on the Getting Started Disc or visit att.com/WirelessTutorials.





BT60 Standard



and





BT90 Extra

Capacity Battery

and

cover



Micro-to-Mini USB Adapter

Micro USB to 3.5mm Headset Adapter



MOTO O™ 9h



### Insert the SIM Card & Battery



2 minutes

Caution: Don't bend or scratch Subscriber Identity Module (SIM) card. Keep it away from static electricity, water, and dirt.

Your **SIM card** contains your phone number and information like your list of contacts. Your MOTO  $\mathbf{Q}^{\text{TM}}$  9h global comes with two batteries and two battery covers. The BT60 standard battery uses the narrow cover, while the BT90 extra capacity battery requires the larger cover.



## Charge the Battery




🦄 time varies

New batteries are not fully charged.

Plug the battery charger into your smartphone and an electrical outlet. It might take several seconds for charging to start.

**During charging**, you should see a light around the navigation key. **When charging is complete**, your display shows a full battery icon **™**. You can't overcharge your battery.





## Welcome to AT&T

## Insert a Memory Card



You can use a removable microSD memory card to store music, pictures, videos, and other files. For the maximum card size your smartphone supports, check <a href="mailto:att.com/devicesupport">att.com/devicesupport</a>.

- 1. Open the memory slot cover by gently lifting the cover away from the smartphone as shown. The cover remains attached to the smartphone.
- 2. Insert the memory card into the slot, with the card's metal contacts facing the front of the smartphone.
- 3. Put the memory slot cover back in place and push it to close it. The cover clicks into place.

Caution: Do not remove your memory card while your smartphone is using it. Don't bend or scratch your memory card. Keep it away from static electricity, water and dirt.

none.

To see the files on your memory card, press **Start**, then **All Programs > Applications > File Manager** and navigate to the folder called **Storage Card**.




## Turn On Your MOTO Q<sup>™</sup> 9h global



**To turn on your smartphone**, press and release ①. If prompted, enter your password or SIM unlock code.

**To turn off your smartphone**, press and hold of for 3 seconds, then **release** it.

Tip: To change how long your backlight stays on, see "extend battery life" on page 37.





1

## Set Up Your MOTO Q<sup>™</sup> 9h global

#### Connect to AT&T



To connect to the wireless network successfully, your MOTO  $\mathbf{Q}^{\mathsf{m}}$  9h global must be powered on, your wireless service must be active and you must be in a coverage area. On the top right corner of the home screen, you will find the network coverage indicator:



Full coverage





Yx Wireless is turned off

## Learn to Navigate & Type

Tip: If you need help while using your smartphone, visit att.com/WirelessTutorials.

highlighted feature.








To **go back one menu**, press **(**. To **exit any menu or view** without saving any changes, press **(**.

To enter text (such as in a new text message), press your letter keys.

To **delete** characters, press **(**-. Hold **(**-) to keep deleting. To start a **new line**, press **(**-).

As you enter letters, your smartphone might try to **predict** the word. Predictive text has an orange arrow below it.





To accept the prediction, press �� right. To see alternate predictions, **hold** the down arrow on ��. To **turn off** or configure predictive text while you are writing a message, press 🌇 then 🔨 > **Setup**.

**abc** Enters the **letter** shown on a key (such as **Q**). To capitalize the next letter (**Abc**), press ♠ once. To capitalize all letters (**ABC**), press ♠ twice.

Alf Enters a symbol or number on the next key pressed (such as !), then changes to the abc mode to enter letters.

**ALT** Enters **only symbols and numbers** on the keys until you press **a**gain.

Tip: For international characters and other symbols, press [ then 1.



## Set Up Your MOTO Q<sup>™</sup> 9h qlobal

### Make Calls



1 minute

From the home screen, enter a phone number then press 💿 to make a call.

To **voice dial**, press and hold 🖅. When prompted, say "Call." When prompted again, say a number or contact name. When your smartphone rings and/or vibrates, press 10 to answer. To "hang up," press 10.

- To send an incoming call directly to your voicemail, press **Ignore** or **1**.
- To put a call on hold, press ②. To take the call off hold, press ② again.
- To answer a second call and put the current call on hold, press 💽 . Then press 💽 to switch between the two calls. To create a three-way conference call between these calls, press **Menu** > **Conference**.
- To turn the speakerphone on or off, press 📢 during a call. At the top of your display, 🗳 means the speaker is on. The speaker won't work when a car kit or headset is connected.

## Set Up Voicemail 3 minutes



Press and hold 11 to call the voicemail system. The voicemail system asks you to create your password, record your name, then record a greeting.

### Check Voicemail



2 minutes

When you see the voicemail message indicator **a** at the top of your display, press and hold 1 to check your voicemail.





## Text & MMS Messages

In addition to email, you can send and receive text (SMS) and multimedia (MMS) messages.

#### Send Text & MMS Messages



- Press **□** > Messages.
- 2. Press Menu > New > Text Message.
- Enter the contact phone number or email address, with a semicolon (;) between multiple numbers or addresses. As you enter contacts, suggestions appear in a box below the To field.
   Tip: To open your contacts list, just press when you're in the To field.
- Press the navigation key ♠ down to scroll to the message field, then use the keypad to compose a message.
  - Tip: In the message area of an MMS message, you can press **Menu** > **Insert** and select an item to insert.
- Press Send.






## Set Up Your MOTO Q<sup>™</sup> 9h qlobal

#### Take a Photo & Send It 3 minutes

- Press to open the camera viewfinder.
- Point the camera lens at the photo subject.
- Press the *center key* to take a photo.
- Your smartphone saves the picture and shows it in the viewfinder.
  - To send the photo in a multimedia message, press Menu > Send > MMS, then enter a phone number or email address, enter text, and press **Send** (for more detail, see "Send Text & MMS Messages" on page 11).
  - To edit the picture, press Menu > Edit.
  - To view picture properties, like the filename, press **Menu** > **Properties**.

To see the pictures stored on your smartphone, press > Thumbnails, then scroll to the picture and press View. To see pictures stored in another folder or on your memory card, press 📵 > Thumbnails, then press Menu > Folders > My Device and choose the folder.



Before you take a picture, you can press Menu to adjust picture settings.



#### Read Text & MMS Messages




When you receive a message, your smartphone plays an alert and shows a message indicator, such as 🛂.

1. On the home screen, press  $\square$  > **Messages**.

If you do not see your messages, press Menu > Folders > Inbox.

2. Press the *navigation key*  $\diamondsuit$  to select a message. Press the *center key*  $\diamondsuit$  to open it.

When you have a text message open, your cursor blinks in a space at the bottom of the display. Here, you can enter text and press **Send** to reply to the message. If you have exchanged a few messages back and forth in this conversation, you can scroll up to see the previous messages. You can also press **Menu** and choose to **Delete** the message, **Copy/Paste** message text, or other options.





## Set Up Your MOTO Q<sup>™</sup> 9h qlobal

### **Instant Messaging**

If you subscribe to an instant messaging (IM) service, such as Yahoo! Messenger, AOL® Instant Messenger™, or Windows® Live Messenger, you can take the convenience and fun of IM on the go with your smartphone.

#### Sign In



- On the Home Screen, press Start, then All Programs > IM & Email > IM.
- Select the IM community where you are a member and press the *center key* ••••.
- Enter your user name and password, then press **Sign In**. To **start** a conversation, highlight a contact and press the *center key* 💠, enter text, and press **Send Message**. During a conversation, press **Menu** to insert emoticons or end the conversation.

When you are signed in but not in a conversation, press Menu to manage your contacts or groups, change your status, or sign out (to conserve battery life, be sure to sign off IM when not in use).

#### Add an IM Contact



2 minutes

- On the IM main screen, press **Menu** > **Add a contact** or **Add Buddy**.
- Enter the contact's ID and press Add.



### Go to Web Pages



To open your Web browser, press 🖭.

To go to a Web page, press Action > Go to. Enter the Web address and press OK.

- To go to a link in a Web page, use the navigation key \(\bar{\phi}\) to highlight the link and then press the center key \(\bar{\phi}\).
- To add a Web address to your Favorites, open the Web page and press Action
   Bookmark this page.

Note: Not all Web file formats are supported.

Tip: All finished? When you are done with the browser, press **Menu** > **Exit** to close the browser and conserve battery life.

## Shop for Tones, Games, Graphics, &

More



You can purchase and download new ring tones, games, graphics, applications, and more right from your smartphone.

Press Start, then All Programs > ATT Mall

Tip: To see the AT&T Media Mall from your computer, visit att.com/mediamall.

Your browser homepage appears.



Press **Menu** to change browser settings and other options.



## **Access Your Email**

## Choose the Best Email Option for You



You can use your MOTO **Q**™ 9h global to access personal or corporate email:

- Personal email accounts pull email directly from your internet service provider (ISP) like Yahoo!, AOL or Hotmail to your Windows® Mobile powered smartphone. To set up a personal email account on your MOTO Q 9h global, you can use Xpress Mail™. Xpress Mail offers automated setup and synchronization so that changes and deletions on your MOTO Q 9h global also appear in your ISP email account.
- Corporate email accounts like Microsoft® Exchange Server or IBM Lotus Domino, are typically managed by an
  IT organization. To set up corporate email on your MOTO Q 9h global, you can use Xpress Mail for self-service or
  Microsoft® Direct Push and Good Mobile Messaging for IT-managed service.

Note: For functions such as web browsing and email, AT&T recommends that you subscribe to an unlimited data plan. Call AT&T at 611 to sign up for a data plan.



### Set Up Personal Email with Xpress Mail™



Xpress Mail™ works with most email services. If you complete this setup process and your email does not start arriving on your device, check with your email provider to validate eligibility.

- 1. On the home screen, scroll to and select **Get Xpress Mail**.
- 2. Scroll to and select Install Now.
- 3. Scroll to and select Download Now.
- 4. Press Save (the Left Soft Key) to confirm the download.
- Press Save (the Left Soft Key) again to confirm the file name and location for saving. Your smartphone downloads Xpress Mail.
- 6. Press Install (the Left Soft Key) to install Xpress Mail.
- 7. Press **OK** (the **Left Soft Key**) to allow the the soft reset, which just makes your smartphone turn off and on again to finish installing Xpress Mail.
- 8. Press **OK** (the **Right Soft Key**) to accept the license agreement.






### **Access Your Email**

- In Mobile Number, enter your 10-digit (mobile) phone number, then press Next (the Right Soft Key).
- 10. For personal email, select Portal or ISP (and press Next), then select your email provider (and press Next). If your provider is not listed, select More to see more providers.

For corporate email, select Work (and press Next), then select Professional Edition (and press Next), then select Sign up for AT&T Xpress Mail (and press Next). Enter your email address to receive an email with further setup instructions.

- If necessary, press Accept (the Right Soft Key) to accept your email provider's terms of use.
- Enter your **User Name** and **Password** (for your personal email, or the user name and password you created for corporate Xpress Mail), then press **Next** (the **Right Soft Key**).
- 13. Press Register (the Right Soft Key).
- 14. After successfully registering, you can press **OK** (the **Left Soft Key**) to see the XM Settings section. Then, press **Inbox** (the **Left Soft Key**) to open your mail.





## 



To set up corporate Xpress Mail, you need to know our corporate email address and the type of mail server (Microsoft® Exchange Server or IBM Lotus Domino). Once you know this, complete these steps on your work computer, with an Internet connection:

- 1. Go to the Web page http://xpressmailpe.wireless.att.com
- Click on **Register Now** and fill in your information. Note: You will create an Xpress Mail User Name and Password in this step. Please note these for future steps.
- Click **Next** to go to the download page, then click **Download**.
- Click the **Open** or **Run** button to download the software.
- Click **Yes** to install the software
- Click **Next** to begin setup, and follow the on-screen instructions. When prompted for a **user name** and **password**, use those created in step 2 of this procedure.
- 7. When Xpress Mail connects to your corporate email account, you will receive a message confirming it. Complete the setup process with "Set Up Personal Email with Xpress Mail™" on page 17.



## **Access Your Email**

## Set Up IT-Managed Corporate Email



To set up your IT managed corporate email account, you will need a PIN or server address from your corporate IT organization. Contact your IT administrator for more information about Microsoft® Direct Push and Good Mobile Messaging support for the MOTO Q<sup>™</sup> 9h global.

### 



Microsoft Direct Push provides wireless access to your corporate email, contacts, calendar and tasks for Microsoft Exchange Server. Contact your IT administrator for set up instructions (such as server address). Before you use Microsoft Direct Push, activate a "PDA Enterprise for Microsoft" data plan on your AT&T account.

#### Good® Mobile Messaging

Good Mobile Messaging provides wireless access to your corporate email, calendar, contacts, tasks and notes for Microsoft® Exchange Server or IBM Lotus Domino. On your smartphone, select Start > All Programs > IM & Email > **Get Good** to download Good Mobile Messaging to your MOTO Q<sup>™</sup> 9h global. Your IT administrator can give you the PIN you need in order to download and install Good Mobile Messaging. Before you use Good Mobile Messaging, you must activate a "PDA Enterprise for Good" data plan on your AT&T account.





### Send & Receive Email



After email is set up, you can send and receive email from your MOTO  $\mathbf{Q}^{\mathsf{m}}$  9h global. When you receive messages,  $\boxtimes$  appears at the top of your home screen.

- Press █.
- Select your email account (your provider name, Outlook E-mail, or Xpress Mail).
   To write a new message, press Menu > New. Compose a message (to insert items in the message area, press Menu > Insert.), then press Send to send it.

**To select several messages** and delete, mark, or move them, press **Menu** > **Select Messages** and follow the menu prompts.

To use the following shortcut keys: In the inbox, highlight a message and press the key. When a message is open, press and hold the key.

Xpr	ess Mail (4)	<b>₩</b>
$\leq$	Message 4 Sender Message 4 Subject	6:00 PM
$\boxtimes$	Message 3 Sender Message 3 Subject	5:30 PM
$\bigcirc$	Message 2 Sender Message 2 Subject	2:00 PM
$\bigcirc$	Message 1 Sender Message 1 Subject	12:36 PM
	Delete	Menu



## Sync Your Smartphone with Your Computer

## Sync Contacts, Calendar, Email, Music, & More

You can use Microsoft® **ActiveSync version 4.5 or above**, or Windows® **Mobile Device Center** to synchronize your personal information and files between your smartphone and desktop computer.

#### Installing & Setting Up ActiveSync



**Note:** Synchronization software is included on the *Getting Started Disc* packed with your smartphone. Before installing the software, verify that your computer and operating system meet the **minimum requirements** stated at **www.microsoft.com/windowsmobile**, where you can also download the **latest software** for ActiveSync.

- 1. Install Microsoft ActiveSync (for Windows® XP™ or earlier) or Windows Mobile Device Center (for Windows Vista) on your PC.
- 2. After setup completes, connect your smartphone to the PC using the USB data cable. The smartphone drivers install on your computer and then the Sync Setup Wizard automatically starts.
- 3. Follow the instructions on the screen to complete the wizard. Once the wizard is complete, the items you have selected will be synced. You can disconnect your smartphone from your PC, and you may need to restart your PC.

**Note:** If you have wireless ActiveSync set up with an Exchange Server, you cannot also sync email, contacts and calendar with a PC running Microsoft Vista. However, you can synchronize media and transfer files through the cable connection.



#### Sync Music & Other Files With Your Computer



Tip: For best results, choose media files that are 15 frames per second, 320x240 pixels, and 384 kbps.


You will need:

- a computer with media files and a program that manages them. Your smartphone plays WMA, WMV, MP3, AAC, eAAC, eAAC+, WAV, MP4, M4A, 3GP, MIDI, and Real Audio files. For more details, see <a href="att.com/music">att.com/music</a>.
- a microSD memory card (see page 6).
- a USB data cable, or a computer with Bluetooth® capability.

To connect your smartphone to your PC:

- 1. Turn on your smartphone and connect it with the data cable to the USB port on your computer.
- 2. In ActiveSync on your PC, select **Explore** and double-click **My Windows Mobile** device.
- On your computer, find the files you would like to copy to your smartphone and drag them into the folder where you want them (such as My Documents).
- Your files are now available on your smartphone. In the media player, press Menu > Update Library to see the files.

Note: For more detailed information, see "Connecting a mobile device to a PC" in ActiveSync Help on your PC, the Microsoft Web Site for ActiveSync or visit <a href="mailto:att.com/WirelessTutorials">att.com/WirelessTutorials</a>.





## Use Your MOTO Q<sup>™</sup> 9h global for More than Basics

### Find Your Way With AT&T Navigator



AT&T Navigator, with GPS enabled directions, is the fastest way to get where you are going - whether across town or across the country. Find your way with turn-by-turn voice and on-screen driving directions, and navigate around traffic congestion with automatic re-routing. Locate and navigate to restaurants, Wi-Fi hotspots, and more, from more than 10 million business listings.

Note: This feature requires a subscription. For more details about AT&T Navigator, contact AT&T or visit att.com/navigator.

#### Download and Install AT&T Navigator

- On the home screen press Start, then All Programs > Applications > AT&T GPS > Get AT&T Navigator.
   Your browser opens a Web page for AT&T Navigator.
- 2 Select Download

Note: If you want to cancel the download and try again later, press Cancel. You will lose any progress up to this point.

#### Log Into AT&T Navigator

- After you install AT&T Navigator, press Start, then All Programs > AT&T GPS > ATT Navigator.
   AT&T Navigator asks you to enter your (mobile) phone number, name and AT&T Navigator PIN. You received your AT&T Navigator PIN in a text message when you activated your subscription. To activate a subscription, visit att.com/navigator.
- 2. Enter your information and press **Login**.



#### Generate a Route with AT&T Navigator

- 1. After you log into AT&T Navigator, select **Drive To**.
- 2. Select Address and choose Type It.
- 3. Enter the address for your destination, then select **Done**. AT&T Navigator validates the address and generates your route. Congratulations! You generated a route!

#### Close AT&T Navigator

To exit AT&T Navigator, go to the main AT&T Navigator menu and press Exit.



## Use Your MOTO Q<sup>™</sup> 9h global for More than Basics

#### AT&T Music™

AT&T Music™ is the ultimate, integrated, on-the-go music experience. Wherever you go, AT&T Music will connect you to your music with a touch of a button. You can listen to your music, discover the latest songs, music news, concert updates, streaming music, ringtones, Answer Tones™, and watch the latest music videos.

You can access all AT&T Music features by pressing **Start**, then **All Programs** > **AT&T Music**.

Note: The **Streaming Music** application uses a large amount of data, and you are responsible for all data charges incurred. **AT&T strongly recommends that you subscribe to an unlimited data plan in addition to this purchase.** Call AT&T at 611 to sign up for the appropriate unlimited data package.

To update your library after you sync or download music files to your smartphone (as described on page 23), press > Windows Media Player, then press Menu > Update Library, then press Done.

To play music, press 🗗 > Windows Media Player > My Music > All Music, then press the *center key* • to choose a song. In the music player:

- To mute and unmute sound, press #.
- To skip to the previous or next file, press the *navigation key* left or right.
- To increase or decrease the volume, press the *navigation key* **•** up or down.
- To fast forward or rewind, press and hold the *navigation key* left or right.
- To play or pause, press the *center key* •.





## Record a Video Clip

2 minutes

1. Press , then Menu > Video.

Tip: In the video viewfinder, press **Menu** to adjust video settings.


- 2. Point the camera lens at the photo subject.
- 3. Press the *center key* to begin recording a video.
- 4. Press the *center key* to stop recording and save the video, or press **Pause** to pause recording. To continue a paused recording, press **Resume**.

### Picture & Video Options

In the photo or video viewfinder press **Menu** > **Options** to open the options menu:

- Camera: Set the save location, file name prefix, and compression for photo files.
- Video: Set audio and time limit settings for video files.

Note: In this menu, the General and Slideshow options are for picture files.





## Use Your MOTO Q<sup>™</sup> 9h global for More than Basics

## Play a Video Clip

- 1 minute
- Scroll to a video clip.
- Press Play. The video clip plays in the Windows Media Player.

To play videos stored in another folder or on your memory card, press

> Thumbnails, then press Menu > Folders > My Device and choose the location for the folder

Note: To switch to full screen mode and back, press ①. Videos recorded in a low resolution may not play in full screen mode. While watching a video you can change your default view to full screen by pressing **Menu** > **Options** > **Video**. Then select Always and check Scale to fit window.





#### Watch CV

CV brings you quick, on-demand access to high quality news, sports, weather and entertainment video clips.

- 1. On the Home screen press **Start**, then **All Programs** > **Cellular Video**.
- 2. Select the show you want to watch.

#### Watch Live Video with MobiTV

Want video on your smartphone? You've got it. AT&T brings you news, sports, weather, entertainment and more.

To install MobiTV: 3 minutes

- 1. Press Start, then All Programs > Applications > Get MobiTV.
- 2. Download and install the MobiTV application on your AT&T smartphone.

To use MobiTV after you install it, press **Start**, then **All Programs** > **Applications** > **MobiTV**.



## Use Your MOTO Q<sup>™</sup> 9h global for More than Basics

#### Connect a Bluetooth® Wireless Headset

Your smartphone supports Bluetooth wireless *pairing* (also called *linking* or *bonding*). You can pair your smartphone with a Bluetooth headset or car kit, or pair your smartphone with a computer to exchange and synchronize files.

**Note:** The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

#### Pair with a Headset or Handsfree Device



You can pair your smartphone with multiple devices, but you can only use it with one headset device at a time.

- Press Start, then All Programs > Bluetooth > Bluetooth Manager > Hands-free.
   If you are prompted to turn on Bluetooth power, press Yes.
- 2. Make sure the headset or handsfree device is turned on and in pairing or bonding mode (see the device user's guide).
- 3. Press Add (or Menu > Add). The smartphone prompts you to verify the device is ready. Press Search.
- 4. Select the device from the list.
- 5. If prompted, enter the device passkey (such as 0000) and press **Accept**.

Tip: For specific information about the headset or handsfree device, refer to its instructions.



#### Store & Call Contacts

#### Store a Phone Number



4 minutes

- Press Start, then All Programs > Contacts and press New
- Choose whether the contact will be stored on your smartphone (Outlook Contact) or on your SIM card. Contacts on the SIM card can only include a name and number.
- Enter information for the contact.

Tip: While you are entering the number, you can tell your smartphone to pause and then dial more digits (such as a voicemail password or PIN). Press Menu > Insert Pause to insert a 2-second pause (shows as a p) or press Menu > Insert Wait to tell your smartphone to wait for you to press the center key • before dialing the remaining digits (shows as a w). Insert Wait does not work for contacts stored on your SIM card.

Tip: If you get a call from someone who isn't in your list of contacts, you can create a contact from Call History. Just highlight the call and press **Save**.

To load the contacts from your last phone, just insert the SIM card from your last phone (see page 5). Your MOTO Q<sup>™</sup> 9h global reads any contacts your last phone stored on the SIM. If there aren't any contacts on your SIM, check your old phone's manual to see if you can copy its contacts to the SIM or to Microsoft® Outlook on your computer.

To load Microsoft Outlook contacts from your computer, see page 22.

#### Call a Stored Number



- Press Start, then All Programs > Contacts
- Scroll to the number
- 3. Press to call the contact's default number, or select the contact to see the other numbers.



## Use Your MOTO Q<sup>™</sup> 9h global for More than Basics

#### Add & View Calendar Events

Add a New Calendar Event 2 minutes



Press Start, then All Programs > Calendar, then press Menu > New Appointment

Tip: In the **Subject**, you can enter text or press the *center key*  $\stackrel{\bullet}{\bullet}$  to choose from a list of subjects. To schedule an all-day event. select the All day event check box under End time. All-day events do not occupy blocks of time in the calendar; instead, they appear in banners at the top of the calendar.

View a Calendar Event 1 minute



Press **Start**, then **All Programs** > **Calendar** to open the calendar for today.

- To see days before or after today, press the *navigation key* left or right.
- To guickly see a specific date, press Menu > Go to Date.
- To see your whole week's events, press Week.
- To edit an event, scroll to it, press the *center key* , then press **Menu** > **Edit**.

**Shortcut:** Today's events appear on your home screen.

Set a Calendar Event Reminder 3 minutes



The default reminder time for tasks and calendar items is 15 minutes. To change this default: Press Start, then All Programs > Calendar, then press Menu > Tools > Options > Set Reminders



## Manage Finances With Mobile Banking from AT&T

With Mobile Banking, you can check your account balances, securely transfer funds between your eligible accounts, view and pay bills, and review your transaction history. You can access multiple banks, accounts and financial services within one application. To find out if your bank supports Mobile Banking from AT&T, visit <a href="matter:att.com/mobilebanking">att.com/mobilebanking</a> or contact your financial institution.

**To install** Mobile Banking, press **Start**, then **All Programs > Applications > Get Mobile Banking** and follow the directions to download the application.

To activate Mobile Banking after you install it:

- On your computer visit your bank's Web site and enroll in Mobile Banking. You will receive an initialization code.
- On your MOTO Q™ 9h global press Start, then All Programs > Applications > Mobile Banking.
- 3. Enter the **initialization code** when prompted.
- 4. Establish a six-digit PIN. You will need to enter this PIN every time you access Mobile Banking.

**To use** Mobile Banking after you activate it, press **Start**, then **All Programs > Applications > Mobile Banking**.









## Troubleshooting & FAQs

#### My smartphone won't turn on

To turn on your smartphone, press and release ①. If your smartphone does not respond, try holding ②. If that does not work, be sure that the battery is fully charged. If it is, remove and replace the battery, then try to turn the smartphone on.

#### My smartphone's display is frozen

In the event your smartphone does not respond for more than 30 seconds, be sure that the battery is fully charged. If it is, remove and replace the battery, then turn the smartphone back on. If these do not help, you can do a **hard reset** to restart your smartphone, but this erases your personalized settings and any content stored in smartphone memory. To perform a hard reset, remove and replace the battery, then hold down the  $\textcircled{\times}$  and E keys for 5 seconds while turning the smartphone on.

#### I cannot connect to a wireless network

Try performing the following actions:

- Verify that your SIM card is inserted correctly.
- Press and hold until the quick list appears, then select Wireless Manager > Phone > On.

#### I can't hear sound on my smartphone

While you are on a call or playing a media file, press the up volume key (see "change your ringer and earpiece volume" on page 36).

#### I can't choose a song as my ringtone

Make sure the song file is 600kb or smaller and in one of these formats: MIDI, MP3, AAC, AAC+, or eAAC+.



#### I want to charge my device using my computer

If you have an available USB port on your computer and you install the MOTO  $\mathbf{Q}^{\text{TM}}$  9h global Getting Started Disc software on your computer to obtain the required USB drivers, you can connect your MOTO  $\mathbf{Q}$  9h global to your computer to charge the battery when the computer is turned on. Connect the smaller end of the USB cable to the USB port on the side of your MOTO  $\mathbf{Q}$  9h global. Connect the larger end of the USB cable to an available USB port on your computer.

#### What global networks will support my MOTO Q<sup>™</sup> 9h global?

The MOTO  $\bf Q$  9h global is designed to work on GSM/GPRS/EDGE networks in the US (850/1900 MHz), Canada (1900 MHz), and Europe/Asia (900/1800 MHz). It can also use UMTS/HSDPA "3G" networks in the US (850/1900 MHz).

#### What memory card can I use?

You can use microSD memory cards up to 32 GB.



# Tips & Tricks

То	Do this	
open your music, messages, and more	Use shortcut keys to access your AT&T Music ┛, camera and video ⑩, contacts ⑪, calendar ▦, messages 図, and MEdia Net ᠍.	
open the quick list	Press and hold  for quick access to your sound profiles, d	levice lock and wireless manager.
change your ringer and earpiece volume	<b>Tip:</b> To silence your smartphone when it's ringing, just press the <i>side volume keys</i> .	<b>W</b> olume Up
	To change the other caller's voice volume, press volume up/down during a call.  Note: Bluetooth® accessories, such as headsets, have their own volume controls.	Side Select Volume Down Back Key
	To change your ringer and sound profile from the home screen, press and hold to open the Quick List. Then scroll to a profile, such as <b>Normal</b> , <b>Silent</b> , or <b>Vibrate</b> , and press the <i>center key</i> ••.	Quick List 🗵 💷 🖫 1 Power off 2 Wireless Manager
	To change the sound for alerts or other events, press Start, then All Programs > My Stuff > Personalize My Q > Sounds and Ringtones. Highlight the event and select the sound you want to associate with it.	3 Lock 4 Normal 5 Silent 6 Vibrate 7 More
personalize your device	Press Start, then All Programs > My Stuff > Personalize My	Select Cancel  Q to choose sounds and more.



То	Do this
lock the keypad	You can manually lock your smartphone to prevent accidental key presses
	To <b>lock your smartphone</b> , press 📵 then 🖵. Your left soft key becomes <b>Unlock</b> .
	To <b>unlock your keypad</b> , press <b>Unlock</b> and enter your password. Your smartphone uses * if you have not set a password.
	To change your password and lock settings, press the Left Soft key to select Start, then All Programs > Settings > More > Security > Device Lock. Choose a password you will remember. If you forget your password, you will have to perform a hard reset (see the note in the section "Turn On Your MOTO $Q^{\text{TM}}$ 9h global").
use voice commands	To activate voice commands, press and hold . When prompted, say one of the commands listed on the screen (such as "Call" followed by a number or contact name).
use the speakerphone	During a call, press 🗗 to turn the speakerphone on or off.
chcek your voicemail from another phone	Call your 10-digit phone number. During your voicemail greeting, press 🗶 (# in Puerto Rico) then follow the voice prompts.
play music or games on an airplane	To keep using your games and music on a flight, turn off your network and Bluetooth® services.  Press and hold a until the quick list appears, then select Wireless Manager > All.
extend battery life	To reduce the backlight time out, press Start, then All Programs > Settings > More > Power Management > Backlight time out on battery, then choose a short time.
	To extend <b>email send/receive intervals</b> , press , select an email account, press <b>Menu</b> > <b>Settings</b> , and press <b>Next</b> until you can change the <b>Automatic Send/Receive interval</b> . If you have more than one email account set up, choose only one account to automatically send/receive messages.
	To close unused programs, press <b>Start</b> , then <b>All Programs &gt; System Tools &gt; Task Manager</b> . Select the unused program and press <b>Menu &gt; Kill</b> .



Motorola, Inc. Consumer Advocacy Office 1307 East Algonquin Road Schaumburg, IL 60196

#### www.hellomoto.com

- 1-800-331-6456 (United States)
- 1-888-390-6456 (TTY/TDD United States for hearing impaired)
- 1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.


MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Microsoft, Windows and Windows Me are registered trademarks of Microsoft Corporation: and Windows XP is a trademark of Microsoft Corporation.

AT&T, AT&T logo and Your World. Delivered. are trademarks of AT&T Knowledge Ventures.

© 2008 Motorola, Inc. All rights reserved.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Manual Number: 68000201025-A



- 1. Missed Call: Shows \! when you missed a call.
- 2. Voicemail: Shows  $\infty$  when you have new voicemail.
- 3. Message / Bluetooth: Shows ☑ for a new message, or ③ when Bluetooth power is on.
- 4. Call Forward: Shows 4 when call forwarding is on.
- 5. Network: Shows whether your are using a 3G ₺, GPRS ₲, or EDGE ₺ network.
- 6. Profile: Shows when your ring style is Silent (∢×) or Vibrate (⅙). No indicator appears for other ring styles. A ❖ appears when the speakerphone is on.
- 7. Battery Level: Shows the battery charge level
- 8. Signal Strength: Shows the strength of your network connection. Letters or arrows can indicate when your phone is using a 3G M, GPRS G, or EDGE G connection to transfer data.





## Where can I find more information?

Interactive web tutorials, tips & tricks, and FAQs are available at  $\underline{\text{att.com/WirelessTutorials}}$  Select Manufacturer: Motorola and Model: MOTO  $\mathbf{Q}$  9h.

Detailed support including device specifications, user forums and knowledgebase articles are available at att.com/DeviceSupport

For more information about your wireless service account, service plan or network, visit <a href="mailto:att.com/Wireless">att.com/Wireless</a>
For Microsoft® Windows® Mobile support, visit <a href="mailto:www.microsoft.com/windowsmobile/help/smartphone/">www.microsoft.com/windowsmobile/help/smartphone/</a>

## Help on the MOTO Q<sup>™</sup> 9h global

To set up your phone and some basic preferences, press **Start**, then **All Programs > System Tools**For more help, press **Start**, then **All Programs > System Tools > Help and QuickStart**. **> Getting Started**.

### Additional Help

#### • Phone Support Help

Call AT&T Customer Care at 1-800-331-0500 or dial 611 from any AT&T mobile phone for assistance with your phone or account.

#### On Your Computer

To view the User's Guide for your phone, insert the Getting Started CD in your computer and open the guide file.

© 2008 AT&T Intellectual Property. All rights reserved. AT&T, AT&T logo and all other marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.



