



www.LGUSA.com

VX3400

Quick Start Guide



Sleek Design with Dual LCDs




One-Touch Speakerphone



Melody Composer



Voice-Activated Dialing



Getting to Know Your Phone



Speakerphone

Enjoy the convenience of hands-free conversation with a simple touch of one key.

1. From standby mode, press **up** on the Navigation Key.
2. “**Speaker On**” will appear and remain on the screen.
3. Press **up** on the key again to deactivate.
4. “**Speaker Off**” will appear on the screen.



Melody Composer

Compose your own melodies and create unique ringtones to express your individual style.

1. Press the **Left Soft Key** for **Menu** and select **Media (4)**.
2. Select **Melody Composer (8)**, then **Compose Melody (1)**.
3. Select **Keyboard Mode (1)** or **Score Mode (2)** and press **OK**.
4. Press the **Right Soft Key** and select **Help** to learn how to compose a melody.
5. Use the keypad to compose your melody.
6. Press **OK** to play your melody and the **Right Soft Key** to save.



Note: You have the option to choose from a variety of melody styles, instruments, rhythm and tempo.

Voice-Activated Dialing

You'll appreciate the safety and convenience of placing calls without dialing.

1. Press the **Left Soft Key** for **Menu** and select **Contacts (1)**.
2. Select **Voice Dials (6)**.
3. Press the **Left Soft Key** for **New**, select a contact and press **OK**.
4. Select the desired phone number and press **OK**.
5. Press **OK** to record the voice dial tag by following the phone's prompts.



Note: From standby mode, voice-activated dialing can be initiated by pressing the **Voice Dial Key** on the right side of the phone.

Voice Memo Recorder

Keep track of important personal information by recording up to 30 voice memos totalling 4 minutes.

1. From standby mode, press and *hold* the **Voice Memo Key** on the right side of the phone.
2. Start recording after the tone.
3. Press the **Left Soft Key** for **Done** to stop recording.
By default, your message will be listed by date and time.
4. To play message, highlight the voice memo and press **OK**.
5. Press the **Left Soft Key** to **Play**.



Note: Recorded voice memos are stored in **Tools (5)** under **Voice Memo (3)**.

Enhanced Text Messaging

Liven up your text messages by sending them with graphics and sounds.

1. From standby mode, press **down** on the Navigation Key and select **New Message (2)**.
2. Press the **Left Soft Key** for **Contacts** and select a recipient from the **Contacts (1)**, **Recent Calls (2)** or **Recent Addresses (3)** menu, or use the keypad to enter a new e-mail address or phone number and press **OK**.
3. Select **Message** and press **OK**.
4. Enter the message using the keypad.
5. Press the **Right Soft Key** for **Options** to insert quick-texts or objects.
6. Press **OK** once your message is complete.
7. Press the **Left Soft Key** to send.



Optional Accessories

Accessories for productivity, convenience and fashion are available at www.LGUSA.com.



Extended Li-Ion Battery



Swivel Holster



Vehicle Power Charger



Headset



Mobile Charger